

Fret Locations

Scale Length = $L = 22 \frac{3}{4}$ "

Fret Location (x) = $L/2^{(x/12)}$

<u>Fret</u>	<u>Location</u>
0(nut)	22.75"
1	21.47"
2	20.27"
3	19.13"
4	18.06"
5	17.04"
6	16.09"
7	15.18"
8	14.33"
9	13.53"
10	12.77"
11	12.05"
12	11.38"
13	10.74"
14	10.13"
15	9.57"
16	9.03"
17	8.52"
18	8.04"
19	7.60"
20	7.17"
21	6.76"
22	6.38"
23	6.03"