

Lecture 19 - Semiconductor Devices

Lecture 19: Semiconductor Devices
 Kittel Ch. 17, p. 503 - 512
 + extra material in lecture notes

Physics 460 F 2006 Lect 19 1

Comment

- If the universe were a **homogeneous** crystal, it would be a very dull place
- It is the **inhomogeneities** that create our interesting world
- Sun - earth - ...
- Metals - insulators together to make useful circuits
- The power of semiconductors is the ability to control their electrical (and optical) properties to make devices

Physics 460 F 2006 Lect 19 2

Outline

- What is a semiconductor device?
- **Key point 1** - Bands and Fermi energy
 Bands Relative to Fermi energy
- **Key point 2** - inhomogeneous material or doping
 Variation in concentrations of electrons and holes by controlled doping profiles
- **p-n junctions** - rectification- forward - reverse bias
- Metal-semiconductor junctions
 Schottky barriers - rectification
- Solar Cells
- Light emitting diodes
- Bipolar transistor **n-p-n p-n-p**
- Kittel Ch. 17, p. 503 - 512 + added materials in the lecture notes

Physics 460 F 2006 Lect 19 3

What determines the Band Energies and the Fermi Energy?

- Recall that the product $n p = 4 (k_B T / 2 \pi^2)^3 (m_c m_v)^{3/2} \exp(- (E_c - E_v) / k_B T)$ is independent of the Fermi energy
- BUT the concentrations n and p vary depending on the Fermi energy **relative** to the band energies
- $n = 2 (m_c k_B T / 2 \pi^2)^{3/2} \exp(- (E_c - \mu) / k_B T) = N_0 \exp(- (E_c - \mu) / k_B T)$
- $p = 2 (m_v k_B T / 2 \pi^2)^{3/2} \exp(- (\mu - E_v) / k_B T) = P_0 \exp(- (\mu - E_v) / k_B T)$

Physics 460 F 2006 Lect 19 4

Band Energies and the Fermi Energy

- **Key Points:**
- 1A: Band energy **differences**, e.g., $E_{gap} = E_c - E_v$ are intrinsic properties of a material
- 1B: The absolute energy of the bands is **NOT** an intrinsic property. **The electron band energies all shift by $-eV(r)$ due to an electrostatic potential $V(r)$.**

Physics 460 F 2006 Lect 19 5

Band Energies and the Fermi Energy

- **Key Points:**
- 1C: The Fermi energy μ is the energy to add or remove an electron, which is everywhere the same if the system is in equilibrium. One can either work with μ or with the "electrochemical potential" $\mu_e = \mu + eV(r)$ due to an electrostatic potential $V(r)$.

Physics 460 F 2006 Lect 19 6

Lecture 19 - Semiconductor Devices

What determines the Band Energies and the Fermi Energy?


- If there are inhomogeneous variations in the concentrations n and p as a function of position, the relations can be written
- $n = N_0 \exp(-(E_c - eV(r) - \mu)/k_B T) = N_0 \exp(-(E_c - \mu_0)/k_B T)$
- $p = P_0 \exp(-(\mu - E_v + eV(r))/k_B T) = P_0 \exp(-(\mu_0 - E_v)/k_B T)$
- Either form is correct and the relations obey the law of mass action:

$$n p = N_0 P_0 \exp(-(E_c - E_v)/k_B T) = N_0 P_0 \exp(-E_{gap}/k_B T)$$


Physics 460 F 2006 Lect 19 7

Band Energies and the Fermi Energy

- Examples
- Line up of Fermi energy of two metals in contact
- Two semiconductors in contact




- Band are shifted by $-eV(r)$ so that is the same.
- This means that there must be electrostatic potentials $V(r)$ to make this happen



Physics 460 F 2006 Lect 19 8

Inhomogeneous Semiconductors


- First Example: one material doped differently in different regions
- How can this happen?
- Key assumption: variations are slow on the atomic scale - can treat as smoothly varying



Physics 460 F 2006 Lect 19 9


Inhomogeneous Semiconductors

- First Example: one material doped differently in different regions
- Looking more closely at the doping near the boundary:



Physics 460 F 2006 Lect 19 10


p-n junction



Physics 460 F 2006 Lect 19 11

What causes bands to shift?

- Electric fields - just like a capacitor



Physics 460 F 2006 Lect 19 12

Lecture 19 - Semiconductor Devices

What causes bands to shift?

- Electric fields - just like a capacitor

Density $p < n$ implies $L_p > L_n$

Depletion region neutral overall

Electric field E

$-eV(x)$

Physics 460 F 2006 Lect 19 13

Equilibrium

- In equilibrium with no applied voltage there is no net current, but there is always a generation and absorption of holes and electrons across the interface.
- Electrons on p side (n_p) easily go to n side at rate An_p
- Electrons on n side go to p side at rate $C \exp(-\Delta E/k_B T)$

Thermal distribution of carriers

Physics 460 F 2006 Lect 19 14

Equilibrium

- In equilibrium the current density of electrons is given by the difference of terms for left \Rightarrow right and right \Rightarrow left $j = C \exp(-\Delta E/k_B T) - An_p = 0$
- Similarly for holes

$\Delta E = E_L - E_R$

Physics 460 F 2006 Lect 19 15

How can a pn junction be used to make a diode?

- A device that passes current easily in one direction
- Low resistance for voltage applied in one direction (the forward direction)
- High resistance for voltage applied in the other direction (the reverse direction)

Physics 460 F 2006 Lect 19 16

Forward bias

- Apply a voltage V to reduce the difference between the two sides to $\Delta E - e\Delta V$ ($\Delta V > 0$) ($\Delta E = E_L^0 - E_R^0$)

"Built in" Electric field

Battery

Physics 460 F 2006 Lect 19 17

Forward bias

- Reduce the difference between the two sides to $\Delta E = E_L^0 - E_R^0 - e(V_L - V_R) = \Delta E^0 - e\Delta V$ (with $\Delta V > 0$)
- The net electron current is $j = C \exp(-(\Delta E - e\Delta V)/k_B T) - An_p = An_p [\exp(+e|\Delta V|/k_B T) - 1]$
- Similarly for holes
- Current increases exponentially!

$\Delta E^0 - e\Delta V$

Physics 460 F 2006 Lect 19 18

Lecture 19 - Semiconductor Devices

Forward bias

- The difference between bands on the left and right **increases**
- Below is figure of band energies near the "flat band" condition
- Current flows easily**

Physics 460 F 2006 Lect 19 19

Reverse bias

- Apply a voltage V to **increase** the difference between the two sides to $\Delta E + eV$ ($V > 0$)

Physics 460 F 2006 Lect 19 20

Reverse bias

- Current obeys same formula but with **with $\Delta V < 0$**
- Now the net electron current is (Similarly for holes)
 $J = An_p [\exp(-e|\Delta V|/k_B T) - 1]$
- Current saturates at small value!**
- Acts like capacitor with increased depletion width

Physics 460 F 2006 Lect 19 21

Reverse bias

- The difference between bands on the left and right **increases**
- Current saturates at small value!**
- Acts like capacitor with increased depletion width

Physics 460 F 2006 Lect 19 22

Rectification

- I - V characteristic**

Physics 460 F 2006 Lect 19 23

Forward bias (again)

- How does the current actually flow?
- Electrons flow from right, holes from left - combine near the depletion region

Physics 460 F 2006 Lect 19 24

Lecture 19 - Semiconductor Devices


How can a pn junction be used to convert electric current into light?

- A device in which a current leads to emission of light

Physics 460 F 2006 Lect 19 25

Light Emitting Diode


- Forward biased junction in a system where the combination of the electrons and holes creates light
- Example GaAs or GaN



Physics 460 F 2006 Lect 19 26

Forward bias (again)

- Forward biased junction in a system where the combination of the electrons and holes creates light
- Example GaAs or GaN



Physics 460 F 2006 Lect 19 27


How can a pn junction be used to convert light into electric current?

- A device in which absorption current leads of electric current

Physics 460 F 2006 Lect 19 28

Solar Cell


- Light absorbed in depletion region creates electron-hole pairs
- Made of Si, ...



Physics 460 F 2006 Lect 19 29

Solar Cell

- Light absorbed in depletion region creates electron-hole pairs



Physics 460 F 2006 Lect 19 30

Lecture 19 - Semiconductor Devices

Shottky Barrier

Physics 460 F 2006 Lect 19 31

Rectification in Shottky Barrier

- Similar to p-n junction
- Current increases exponentially (until it saturates) for forward bias that tends to make the semiconductor bands bend **less** (in the case of n-type semiconductor the potential is negative on semiconductor)
- Reverse bias acts like capacitor with increased depletion width

Physics 460 F 2006 Lect 19 32

Transistor

- Invented in 1947 - Bardeen, Brattain, Schockley
- Equilibrium

Physics 460 F 2006 Lect 19 33

Transistor

- Applying voltages - one junction forward and the other reverse - (remember holes like to go uphill)

Physics 460 F 2006 Lect 19 34

Transistor

- Amplifier - Small current controls LARGE current

Physics 460 F 2006 Lect 19 35

Summary

- Semiconductor device – inhomogeneous doping to create a structure with electron and hole conduction that can be controlled

Main points

- Key general points:
 - Band gaps are fixed by the material Si, GaAs, ...
 - Bands Relative to Fermi energy determined by doping
 - In equilibrium (no current) the Fermi energy μ is the same everywhere

- Fermi energy and bands shift due to applied voltages

Physics 460 F 2006 Lect 19 36

Lecture 19 - Semiconductor Devices

Summary continued

Main points - continued

- **p-n junctions** - rectification- forward - reverse bias
- Light emitting diode: **electron, hole** \Rightarrow **photon**
- Solar Cell: **photon** \Rightarrow **separated electron and hole**

Other points

(important but you are not responsible for these)

Metal-semiconductor junctions

Schottky barriers - rectification

- Bipolar transistor **n-p-n p-n-p**
- Kittel Ch. 17, p. 503 - 512 + added materials in the lecture notes

Physics 460 F 2006 Lect 19

37

Next time

- Semiconductor structures
Confinement of carriers
by voltages and materials
- **MOSFET** Transistor
- Quantum Wells, Wires, Dots
- Carriers in Quantum Wells in a magnetic field
Quantized Hall effect
- Covered briefly in Kittel Ch 17, p 494-503, 507- 511
- added material in the lecture notes

Physics 460 F 2006 Lect 19

38