



# Lecture 18: Semiconductors - continued (Kittel Ch. 8)



**Donors and acceptors**



**Transport of charge  
and energy**

# Outline

- **More on concentrations of electrons and holes in Semiconductors**  
**Control of conductivity by **doping** (impurities)**
- **Mobility and conductivity**
- **Thermoelectric effects**
- **Carriers in a magnetic field**  
**Cyclotron resonance**  
**Hall effect**  
**(Read Kittel Ch 8)**

# Law of Mass Action (from last time)

- Product

$$n p = 4 (k_B T / 2 \pi^2)^3 (m_c m_v)^{3/2} \exp(- (E_c - E_v) / k_B T)$$

is independent of the Fermi energy

- Even though  $n$  and  $p$  vary by huge amounts, the product  $np$  is constant!
- Why?  
There is an **equilibrium** between electrons and holes! Like a chemical reaction, the **reaction rate for an electron to fill a hole is proportional to the product of their densities**. If one creates more electrons by some process, they will tend to fill more of the holes leaving fewer holes, etc.


# Control of carriers by “doping”

- Impure crystals may have added electrons or holes that change the balance from an intrinsic ideal crystal.
- If an impurity atom adds an electron, it is called a “donor”
- If an impurity atom subtracts an electron, it is called a “acceptor” (it adds a hole)
- The Fermi energy changes (n and p change)
- But (Law of mass action ) the product  $np = 4 (k_B T / 2 \pi^2)^3 (m_c m_v)^{3/2} \exp( -(E_c - E_v) / k_B T )$  does not change!
- Even though n and p vary by huge amounts, the product np is constant!

# What does it mean to say an impurity atom adds or subtracts an electron?

- Consider replacing an atom with one that has one more electron (and one more proton), e.g., P in Si, As in Ge, Zn replacing As in GaAs, ....
- Question:
  - Is that electron bound to the impurity site?  
Or is it free to move and count as an electron charge carrier?
- The probability that it escapes depends on the crystal and the impurity --- But if it escapes from the impurity, then it acts as an added electron independent of the nature of the impurity
- Similar argument for holes

# Substitution Impurities in Diamond or Zinc-blende crystals



Impurity substituting for host atom, e.g.,

Donors: P in Si

Se on As site in GaAs

Acceptors: B in Si

Zn on Ga site in GaAs

Zinc-blende structure crystal (e.g., GaAs)

Diamond (e.g., Si) if pink and grey atoms are the same

# Binding of electron to impurity

- Simplest approximation – accurate in many cases - qualitatively correct in others (Kittel p 210)
- Electron around impurity is **exactly like a hydrogen atom** -- **except** that the electron has **effective mass  $m^*$**  and the Coulomb interaction is reduced by the **dielectric constant  $\epsilon$**


$$m \rightarrow m^*; \quad e^2 \rightarrow e^2 / \epsilon$$

- The binding is (see back inside cover of Kittel)

$$\begin{aligned} E_{\text{binding}} &= (e^4 m^* / 2 \epsilon^2 \hbar^2) \\ &= (1 / \epsilon^2) (m^* / m) 13.6 \text{ eV} \end{aligned}$$

- The radius is:

$$\begin{aligned} a_{\text{binding}} &= (\epsilon \hbar^2 / m^* e^2) = \epsilon (m / m^*) a_{\text{Bohr}} \\ &= \epsilon (m / m^*) .053 \text{ nm} \end{aligned}$$



# Binding of electron to impurity

- Typical values in semiconductors

$$m^* \sim 0.01 - 1 m;$$


$$\epsilon \sim 5 - 20$$

- Thus binding energies are

$$E_{\text{binding}} \sim 0.0005 - 0.5 \text{ eV}$$

$$\sim 5 \text{ K} - 5,000 \text{ K}$$

- Sizes  $a \sim 2.5 - 50 \text{ nm}$



- In many cases the binding can be **very weak** and the size much greater than atomic sizes
- Holes are similar (but often  $m^*$  is larger)




# Thermal ionization of donors and acceptors

- Suppose we have donors with binding energy much less than the band gap (the usual case).
- The fraction of ionized donors can be worked out simply if the density of donor atoms  $N_d$  is much greater than the density of acceptors and intrinsic density of holes and electrons (otherwise it is messy)
- Then the density of ionized donors  $N_d^+$  equals the density  $n$  of electrons that escape, which can be found by the same approach as the density of electrons and holes for an intrinsic crystal.

# Thermal ionization of donors and acceptors



- Assuming  $k_B T \ll E_{\text{binding}}$  the result is (Kittel p 213)

$$n = 2(m_c k_B T / 2 \pi^2)^{3/2} N_d^{1/2} \exp(-E_{\text{binding}} / k_B T)$$



# When is a doped semiconductor a metal?


- If the density of donors (or acceptors) is large then each impurity is not isolated
- The picture of an isolated hydrogen-like bound state does not apply
- What happens if the states overlap?



- The system becomes “metallic” !
- Similar to Na metal in the sense that the electrons are delocalized and conduct electricity even at  $T=0$
- This is a metal if the distance between the impurity atoms is comparable to or less than the radius  $a$
- There are also special cases – see later


# Conductivity with electrons and holes

- Both electrons and holes contribute to conductivity
- Current density  $j = \text{density} \times \text{charge} \times \text{velocity}$   
$$J = n q_e v_e + p q_h v_h = -n e v_e + p e v_h$$
- Note:  $e = |\text{charge of electron}| > 0$



# Thermopower and Peltier Effect

- Both electrons and holes contribute to conductivity and conduct heat
- The Peltier effect is the generation of a heat current  $J_u$  due to an electric current  $J_q$  in the absence of a thermal gradient
- Electrons and holes tend to cancel - can give either sign - one way to determine whether electrons or holes dominate the transport!




# Thermopower and Peltier Effect

- Quantitative definition: **Peltier coefficient is the ratio of energy to charge transported for each carrier**

**Surprising?**


- The energy for an electron is  $E_c - \mu + (3/2) K_B T$ ; and for a hole is  $\mu - E_v + (3/2) K_B T$
- $$\Pi_e = (E_c - \mu + (3/2) K_B T) / q_e = - (E_c - \mu + (3/2) K_B T) / e$$

$$\Pi_h = (\mu - E_v + (3/2) K_B T) / q_h = + (\mu - E_v + (3/2) K_B T) / e$$




# How a solid state refrigerator works

- **The Peltier effect** is the generation of a heat current  $\underline{J}_U$  due to an electric current  $\underline{J}_q$  **in the absence of a thermal gradient**
- **Why semiconductors?** Because  $\Pi$  is so large due to the large value of the energy per carrier ( $E_c - \mu + (3/2) K_B T$ ) or ( $\mu - E_v + (3/2) K_B T$ )
- **Demonstration**



# Thermopower and Peltier Effect


- Recall: Both electrons and holes contribute to conductivity and conduct heat
- **The thermoelectric effect** is the generation of an electrical voltage by a heat current  $\underline{J}_U$  in the absence of an electric current.
- Just as in Peltier effect, electrons and holes tend to cancel - can give either sign






# Thermopower

- If there is a thermal gradient but no electrical current, there must be an electric field to prevent the current
- The logic is very similar to the Hall effect and leads to the expression for the electric field needed to prevent electrical current




# Thermopower

- This leads to thermopower: generation of power from heat flow (by allowing the current to flow through a circuit)



# Mobility

- Characterizes the quality of a semiconductor for electron and hole conduction separately
- Recall: Current density  $j = \text{density} \times \text{charge} \times \text{velocity}$   
$$J = n q_e v_e + p q_h v_h = -n e v_e + p e v_h$$
- Define **mobility**  $\mu = \text{speed per unit field} = v/E$   
$$J = (n \mu_e + p \mu_h) e E$$



**Note: the symbols  $\mu_e$  and  $\mu_h$  denote mobility (Do not confuse with the chemical potential  $\mu$ )**


# Experiments:

**How do we know holes are positive?  
How do we know that electrons act  
like they have effective masses?**

- **Experiments in magnetic fields**
  - **Hall Effect**
  - **Cyclotron resonance**

# Hall Effect I

- From our analysis before  
Adding a perpendicular magnetic field causes the electrons and holes to be pushed the **same** direction with force -- but since their charges are opposite, the **current in the y direction tends to cancel**




# Hall Effect II

- In order to have no current in the y direction, we must have electric field in the y direction, i.e.,  

$$j_y = (n \mu_e + p \mu_h) e E_y + (-n \mu_e |v_e| + p \mu_h |v_h|) e B_z = 0$$
- Thus  $E_y = B_z (-n \mu_e |v_e| + p \mu_h |v_h|) / (n \mu_e + p \mu_h)$

- $R_{\text{Hall}} = E_{\text{Hall}} / j B = (1/e) (-n \mu_e^2 + p \mu_h^2) / (n \mu_e + p \mu_h)^2$   
 (Kittel problem 3)




# Cyclotron resonance

- **Measures effective mass directly**
- **Subtle points**
- **THIS IS EXTRA MATERIAL – NOT REQUIRED FOR HOMEWORK OR THE EXAM**

# Motion of carrier in Magnetic field

- Force:  $q (\underline{v} \times \underline{B}) = \hbar d\underline{k}/dt$
- Electron moves on **constant energy surface**, with only change in direction of  $\underline{k}$
- Thus  $d\underline{k}/dt = -e |\underline{v} \times \underline{B}| / \hbar = - (e/m^*) k B$
- Isotropic bands (same in all directions like for free electrons): period of revolution in k space is  $2\pi k / (dk/dt) = 2\pi / \omega_c$  and  $\omega_c = qB/m^*$




**Cyclotron Resonance**



# Cyclotron Resonance

- Experimental way to measure effective masses
- Magnetic field  $\underline{\mathbf{B}}$  defines particular direction in space
- Electrons rotate in plane perpendicular to  $\underline{\mathbf{B}}$  with a period of revolution  $\omega_c = qB/m^*$
- Observed experimentally by the absorption of **electromagnetic waves at frequency  $\omega_c$**
- Interpretation: wave causes electron bunches to move in circle - resonance occurs when electrons and wave are in phase at frequency  $\omega_c$




# Real Bands in a Semiconductor - Si

Fermi Energy


Minimum

Filled lower bands  
if there are  
8 electrons  
per cell




# What if minimum is not at $k = 0$ ?

- Multiple equivalent minima
- Anisotropic mass



# Multiple minima


- Conduction band of Si - 6 minima along  $(k_x, 0, 0)$ ,  $(0, k_y, 0)$ ,  $(0, 0, k_z)$  directions



- In Ge, 8 minima along directions with  $|k_x| = |k_y| = k_z$


# Anisotropic Mass

- Consider only one minimum at  $\underline{k} = (k_{\min}, 0, 0)$
- Anisotropic mass:  $\frac{d^2E}{d^2k_x} \neq \frac{d^2E}{d^2k_y} = \frac{d^2E}{d^2k_z}$




# Constant energy surfaces

- Around each of the the minima, the surfaces of constant energy in  $k$  space are circles or ellipses
- Example of Si



# Cyclotron Resonance

- Dependence upon **direction** of magnetic field **B** shows the anisotropy of the mass
- Example: In Si all along **B** any cubic axis is the same. In each direction there are two resonance frequencies  $\omega_c = qB/m^*$  corresponding two different masses for motion perpendicular to **B**



# Summary for Today

- Control of conductivity by doping (impurities)
  - **Donors** and **acceptors**
  - Hydrogenic equations for binding
  - Important that binding be weak for carrier to escape and be able to move
- Conductivity and **Mobility**
- Thermoelectric effects
  - Peltier Effect
  - Thermopower
  - Sign of carrier important
- Carriers in a magnetic field
  - Hall effect
  - Cyclotron resonance (extra – not required)

(Read Kittel Ch 8)



# Summary of Semiconductors I

- Typical bands - understanding from nearly free electron picture
- Optical properties - (direct vs indirect gap)
- Motion of wave packets  $\underline{F} = \hbar \underline{dk}/dt$
- Group velocity
- Effective mass  $m^*$ :  $\frac{1}{m^*} = \frac{1}{\hbar^2} \frac{d^2E}{d^2\underline{k}}$
- $m^*$  tends to be small if the gap is small
- Negative electrons; positive holes
- Law of mass action:  $np = \text{“constant”}$
- Doping and concentrations of electrons, holes  
Donors, acceptors  
Binding of carrier to impurity site

# Summary of Semiconductors II

- **Thermoelectric effects: Peltier; Thermopower**  
**Sign of carrier important**
- **Carriers in a magnetic field**  
**Hall effect**  
**Cyclotron resonance (extra – not required)**  
**Sign of carrier important**
- **(Read Kittel Ch 8)**
- **LATER: Inhomogeneous Semiconductors - e.g.,**  
**variations in dopin in space, p-n junctions,**

# Next time

- Semiconductor devices
- **Created by inhomogeneous material or doping**  
Variation in concentrations of electrons and holes by controlled doping profiles
- **p-n junctions** - rectification- forward - reverse bias
- Metal-semiconductor junctions  
**Schottky barriers** - rectification
- Solar Cells
- Light emitting diodes
- Bipolar transistor **n-p-n** **p-n-p**
- (Kittel Ch. 17, p. 503 - 512 + extra class notes)